

Harness Chest Ascender Installation Instructions



Step 1

Open harness trapezoid link and remove chest strap.



Step 2

Insert sewn loop end of strap onto trapezoid link. Slide buckle down along strap toward trapezoid link.



Step 3

Attach chest strap to trapezoid link.



Step 4

Feed strap through chest sternal D ring lower slot.



Step 5

Attach chest ascender onto trapezoid link.



Step 6

Feed strap through chest ascender from back to front.



Step 7

Feed strap back through chest ascender sternal D ring lower slot.



Step 8

Position strap and tension to begin insertion into buckle. Close trapezoid link and secure with wrench.



Step 9

Insert strap into upper slot of buckle.



Step 10

Insert strap into lower slot of buckle.



Step 11

Insert strap up and through the upper slot of buckle. Any additional strap material can be carefully trimmed and heat sealed.



Use

Insert rope into chest ascender for rope ascending techniques. Tighten chest strap for ascending mode.