

LIMITED WARRANTY

Yates Gear Inc. warrants for one year from the purchase date and only to the original retail buyer that our products are free from defects in material and workmanship. If the buyer discovers a warranty related defect, the buyer should return the product to Yates Gear Inc. Yates Gear Inc. reserves the option to repair or replace any product returned under warranty. That is the extent of our liability under this warranty and, upon the expiration of the applicable warranty period, all such liability shall terminate.

WARRANTY EXCLUSIONS

Yates Gear Inc. does not warrant products against normal wear and tear, unauthorized modification or alteration, improper use, improper maintenance, accident, misuse, negligence, damage, or if the product is used for a purpose for which it was not designed. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Except as expressly stated in this warranty, Yates Gear Inc. shall not be liable for direct, indirect, incidental, or other types of damages arising out of, or resulting from the use of the product.

WARNING

Products manufactured by Yates Gear Inc. are intended for use by professionals trained and experienced in the use, inspection, and maintenance of these products. Many products which Yates manufactures are used in high angle environments which pose a very substantial risk of serious injury or death. You must read and understand all of the manufacturer's instructions before use. Any person purchasing this equipment assumes the responsibility for seeking proper training in its use. Purchaser also assumes all risk for any injury or damage sustained while using any of this equipment. Failure to follow these warnings increases the risk of injury and death.

KEEP THIS USER INSTRUCTIONS/INFORMATION SHEET AS A PERMANENT RECORD AFTER IT IS SEPARATED FROM THE HARNESS/BELT, AND MAKE A COPY TO BE KEPT WITH THE HARNESS/BELT.

It is suggested that the user refer to this user information sheet before and after each use of the harness/belt.

Do not alter or intentionally misuse this harness in any way. Any alterations or repairs to this harness should be conducted by the manufacturer only.

Use caution when using this equipment around moving machinery, electrical hazards, sharp edges, chemical hazards and high heat environment or flame. Carry the harness/belt where it will be protected as the harness/belt could melt or burn and fail if exposed to flame or high temperature.

This sheet has been prepared in accordance with the requirements of NFPA 2500 (1983) 2022 edition.

If you have any questions concerning the condition of your harness/belt, or have any doubt about putting it into service contact manufacturer.

YATES GEAR INC.
2608 HARTNELL AVE. SUITE 6, REDDING, CA. 96002
PHONE/FAX 800-YATES-16 (800-928-3716)
PHONE 530-222-4606 FAX 530-222-4640
WWW.YATESGEAR.COM


Rev. A

Yates
371/371XL
KEVLAR TRUCK
ESCAPE BELT
FIRE-ESC
FIRE ESCAPE BELT

WARNING! DO NOT REMOVE THIS LABEL

- You could be killed or seriously injured if you do not read and understand this label before using harness.
- Special training and knowledge are required to use this harness.
- The user is responsible for understanding the intended use of this harness.
- You must thoroughly read and understand all manufacturer's instructions before use.
- Use and respect harness only in accordance with the manufacturer's instructions.
- Refer to additional manufacturer's instructions furnished with this harness before use.
- All equipment must be used in accordance with the instructions of the manufacturer.

Yates Gear Inc., 2608 Hartnell Ave., Redding, CA 96002
Phone: 1-800-928-3716 for important safety information. Do not remove this label!



CERTIFIED
SAFETY US
MH15047

MANUFACTURED BY YATES GEAR, INC.
MADE IN USA. MATERIAL: KEVLAR
MEETS THE BELT REQUIREMENTS
OF NFPA 1983 INCORPORATED IN THE
2022 EDITION OF NFPA 2500 AND THE
OPTIONAL FLAME RESISTANCE
REQUIREMENTS OF NFPA 1983.
TYPE LADDER/ESCAPE
DO NOT REMOVE THIS LABEL!

TYPE OF BELT: _____

LOT & DATE OF MFG. _____

LADDER/ESCAPE BELT: _____

FITS WAIST SIZE _____

2608 HARTNELL AVE. #6 REDDING, CA 96002 800-928-3716

Labels Located Inside Belt

371 / 371XL & FIRE-ESC BELTS

Classified by UL to meet the belt requirements of NFPA 2500 (1983) Standard on Fire Service Life Safety Rope and Equipment for Emergency Services 2022 edition; type: escape. Designed for use as an escape belt. This harness is constructed of heat resistant kevlar webbing and thread.

USAGE AND APPLICATIONS

Forged D ring located at the front waist level of belt is designed for NFPA personal emergency escape applications. This attachment point should be used for rappel and positioning connections.

Maximum user weight (excluding garments and equipment) 300 lbs.

Design load 300 lbs. per NFPA 2500(1983) 2022 edition.

BEFORE USE

The techniques employed in the proper and safe use of this equipment may only be learned through personal instruction received from an instructor who is well-qualified in all phases of vertical rope work. Such instruction will include an evaluation of your comprehension of, and ability to perform, the tasks required to safely and efficiently use this equipment. Never attempt its use until you have received such instruction and are believed competent by your instructor.

DONNING AND FITTING THE HARNESS

First inspect entire harness: see section Maintenance, Service, Storage

STEP 1: Locate D ring on harness. Hold up harness by this D ring ensure that the waist strap is not twisted.

STEP 2: Secure waist belt portion with quick connect snap hook and D ring adjuster assembly. Adjust webbing to be snug and safety lock waist belt webbing by backing it off through D ring assembly.

STEP 3: Adjust webbing and tie off waist belt webbing by backing it off through D ring assembly.

STEP 4: Adjust webbing to be snug and secure under belt.

SHARP EDGES

Avoid working where the harness will be in contact with, or abrade against, unprotected or sharp edges. If working with this equipment near sharp edges is unavoidable, protection against cutting should be provided by using a heavy pad or other means over the exposed edge.

ROLL OUT

When using a hook to connect to an anchor or when coupling components of a system together, be certain accidental disengagement (roll out) cannot occur. Roll out occurs when a hook is snapped into an undersized ring or non-compatible shaped connector (D ring) causing the hook's gate or keeper to accidentally open and release. Self-locking snap hooks or self-locking and self-closing gate carabiners should be used to reduce the possibility of roll out. Do not attach two snap hooks onto one D ring.

AFTER A FALL

Harnesses which have been subject to the forces involved in arresting a fall must be removed from service and destroyed.

MAINTENANCE, SERVICE, STORAGE

Before and after each use, inspect this harness to ensure that it is in a serviceable condition. Check for worn or damaged parts. Ensure all hardware (D rings, buckles, etc.) are present. Inspect to ensure that all buckles work properly and that they do not have any sharp edges, burrs, cracks or corrosion. Inspect webbing for wear, cuts, burns, frayed edges or other damage. Inspect all stitching for abrasion, discoloration and wear to ensure integrity. Thoroughly inspect harness after any period of extended storage. Store harness in a cool, dry, clean environment out of direct sunlight. Do not expose harness to flame or high temperature environments. Avoid contact with any corrosive or caustic chemical agents such as acids, bases, or petroleum products. Discontinue use of product if it has come in contact with any of the above listed or any suspect chemical agents. Avoid storage and use of harness in areas where chemical vapors may exist. Discontinue use of harness and remove from service if inspection reveals an unsafe condition.

CLEANING

Clean harness with warm water in a mild detergent solution. Wipe off hardware with clean, dry, cloth and hang to air dry. Do not force dry with heat.

ADDITIONAL INFORMATION

Additional information regarding this type of equipment can be found in NFPA 1500, NFPA 1858 and, NFPA 1983, incorporated in the 2022 edition of NFPA 2500.

RECORDS

It is suggested that the user of this harness keep a permanent record listing the date and results of each usage inspection. Such record should show, as a minimum, inspection criteria as written in section Maintenance, Service, Storage.

USE OF THIS USER INFORMATION SHEET

It is suggested that this user information sheet be retained in a permanent record after it is separated from the harness/belt, and that a copy of it be kept with the harness/belt.


It is suggested that the user refer to this user information sheet before and after each use of the harness/belt.

Quick Connect Snap Hook and D Ring Adjuster Assembly

Step 1: Pull on tail end of webbing to tighten assembly

Step 2: Insert tail end of webbing through D portion of adjuster

Step 3: Tighten tail of webbing under the assembly and secure the tail in elastic keepers



WARNING!

No manufacturer can predict every potential hazard that exists with the use of any particular equipment. Yates Gear is not responsible for the mis-use of equipment or the negligence of end users. Training from competent, qualified trainers proven to be knowledgeable in its use is required prior to the use of this product.

- You could be killed or seriously injured if you do not read and understand the user information before using this equipment.
- This product is part of a personal protective, rescue or work support system.
- Special training and knowledge are required to use this equipment.
- You must thoroughly read and understand all manufacturer's instructions before use.
- You must read and follow the manufacturer's instructions for this product and each component of the complete system.
- Use and inspect this equipment only in accordance with these instructions.
- You are responsible for understanding the intended use of this harness, and the intended application and use of each of the multiple attachment points located on this harness.
- Only make compatible connections.

- Avoid sharp edges and abrasive surfaces.
- Do not loop positioning lanyards around small diameter structural members.
- Do not alter this equipment in any way.
- Do not misuse this equipment in any way.
- Do not expose this equipment to harmful chemicals.
- Do not use this equipment around moving machinery, electrical hazards, sharp edges, or abrasive surfaces without competent analysis that the user is protected from potential harm.
- Never use combinations of components and subsystems that may affect or interfere with the safe function of this equipment.
- The user of this equipment should formulate a rescue plan and the means at hand to implement it when using this equipment.
- These manufacturer's instructions must be provided to the end user of this harness.
- User must include harness stretch (6 inches), D ring/connector length, settling of the user's body and all other contributing elements in all clearance calculations.

